


# LODGE

The code letters designated to each plug precisely describe it, Individual letters referring to individual aspects of the spark plug.

The meaning of these type numbers is shown below:-

1st letter

B  
C  
H



These refer to the heat value of the plug.

Subsequent letters

A - 3/8" reach

L - 3/4" reach

N - non detachable

R - racing

Y - extended nose

V - heavy duty

T - taper seat